HK	HONG KONG

Diagram / Parts List

UB402MP

BLOWER ATTACHMENT

2024/12

(HK) UB402MP / BLOWER ATTACHMENT



HK HONG KONG

UB402MP / BLOWER ATTACHMENT

Item	Sub	Parts No.	Parts Description	Qty	I/C	E/C No.	Close No.	Remark
001		413P21-3	NOZZLE	1				
002		413P22-1	ADAPTER	1				
003		266324-6	TAPPING SCREW 4X22	4				
004		413P23-9	HOUSING A	1				
005		252286-4	COLLARED HEX.LOCK NUT M5-8	1				
006		240242-6	FAN 120	1				
007		266326-2	TAPPING SCREW 4X18	3				
008		413P25-5	BEARING COVER	1				
009		210005-4	BALL BEARING 608DDW	1				
010		327B55-5	SPINDLE	1				
011		210059-1	BALL BEARING 6000DDW	1				
012		141R20-4	HOUSING B COMPLETE	1				
	C10	8012T7-9	CAUTION LABEL	1				
013		266326-2	TAPPING SCREW 4X18	3				
014		413P26-3	REAR COVER	1				
015		961012-7	STOP RING E-6	1				
016		266420-0	TAPPING SCREW 5X20	1				
017		266326-2	TAPPING SCREW 4X18	1				
018		327415-9	SHAFT	1				
019		141N43-8	SHAFT PIPE COMPLETE	1				
020		424434-7	CAP 24	1				
021		8066S3-9	SOUND LABEL	1				
022		8588T8-4	UB402MP NAME PLATE	1				
F01		1912R8-4	UB402MP BLOWER ATTACHMENT SET	1				

Y:

Interchange
O : Yes
X : No
< : the new part can be substituted for the current.
> : the current part can be substituted for the new.
S : Interchangeable as a set.